ATIS 133.8
LOS ANGELES TOWER
N 133.9
S 120.95
GND CON
N 121.65
S 121.75
CLNC DEL 121.4

CAUTION: High volume of vehicular traffic -- service roads cross taxiways throughout the airport.



WARNING

Landing Aircraft - Short distance between runways. Expect to hold short of parallel runways. Manage your taxi speed. Do not cross the hold bars to the parallel runway without ATC clearance.

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES. READBACK ALL RUNWAY ASSIGNMENTS. READBACK OF ALL RUNWAY HOLD SHORT INSTRUCTIONS IS REQUIRED.

Last updated 4 Jan 2008

Hot Spot Chart
NOT FOR NAVIGATION
LOS ANGELES INTL (LAX)
LOS ANGELES, CALIFORNIA

ATIS 133.8
LOS ANGELES TOWER
N 133.9
S 120.95
GND CON
N 121.65
S 121.75
CLNC DEL 121.4

CAUTION: High volume of vehicular traffic -- service roads cross taxiways throughout the airport.



WARNING

Landing Aircraft - Short distance between runways. Expect to hold short of parallel runways. Manage your taxi speed. Do not cross the hold bars to the parallel runway without ATC clearance.

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES. READBACK ALL RUNWAY ASSIGNMENTS. READBACK OF ALL RUNWAY HOLD SHORT INSTRUCTIONS IS REQUIRED.

Last updated 4 Jan 2008

Hot Spot Chart
NOT FOR NAVIGATION
LOS ANGELES, CALIFORNIA
LOS ANGELES INTL (LAX)